


# USER'S GUIDE



## WIRING AND OPERATION:

1. Connect a jump cable from LNB to satellite finder's "TO LNB" input.
2. Connect the "TO REC" a 13V~ 18V DC power which come from satellite receiver.
3. Make sure that satellite finder is properly connected. Plug in the AC cord and turn on the satellite receiver.
4. Make coarse dish alignment by setting azimuth and inclination. Turn knob clockwise to make the third LED on.
5. Adjust dish position, feedhorn position, and polarization to make the more LED on. If all LED on, turn off the last two LED by turning level control counterclockwise.
6. Remove the jump cable and satellite finder. Resume connection of satellite receiver and LNB.

## IMPORTANT:

- When using this unit to install C band dish, you must not place the FINDER in front of dish to avoid always all LED on.
- When using high gain LNB, gain that higher than 60dB, insert a 5dB power passing attenuator in between LNB and satellite finder, or replace the jump cable to be a 20ft RG-59U.
- If the LED is sparking, the sensitivity is too high, Low down the input signal by inserting a passing attenuator in between LNB and satellite finder.

## SPECIFICATION:

Frequency Range	950~2150MHz
Gain	17dB
Power Supply	DC13-18V
Operating Range*	LNB Gain=52~60dB

\* : Insert a 5dB attenuator when operating with LNB gain=60~65dB

*Note: All specifications cited in this leaflet are subject to change without notice*